



## Installation Steps

1. The floor area must be cleaned free from oil, paint and any other contamination. The area must also be structurally sound, flat and level.
2. Mark out walls and floor area to be waterproofed using a Warmup recommended contact adhesive. Spray the shower base area and sheet membrane with adhesive. Dress the sheet membrane into an 80mm Warmup clamp flange. Secure the sheet membrane to form a pan liner coming up the shower 150mm weld up corner folds.
3. Cut the sheet membrane to fit the walls (allow for minimum 50mm laps on all joints. Glue the sheet membrane to the walls - make sure all joints are heat-welded.
4. Measure and cut the Marmox preformed shower base to size - glue into position using an impervious adhesive. Make sure all joints are filled with this adhesive.
5. Check falls in the shower base [ Channel drains 1:100 and Centre drains 1:50]
6. Concrete floors - level entry three walls including glass screens. Extend the waterproofing out minimum 1m from the shower cubicle and all floor to wall junctions to be waterproofed.
7. Timber floors - level entry whole floor area must be waterproofed and floor to wall junction as well.
8. Make sure the waterstops are sealed onto the shower base or hob upstands.

1:2